

COLOURSTONE RESIN BOUND SURFACE CLEANING SCHEDULE



REMOVE ANY LOOSE DEBRIS ESPECIALLY SMALL STONES OR SHINGLE ON A REGULAR BASIS TO REDUCE RISK ON PIN POINT DAMAGE TO THE RESIN BOUND SURFACE.



A JET WASH, STIFF BRUSH OR POWER HOSE (UP TO 1.5 BAR OF PRESSURE) CAN BE USED TO REMOVE DIRT, DEBRIS ETC.



A WEED OR MOSS KILLER IS RECOMMENDED FOR USE IF REQUIRED AND HAS NO EFFECT ON THE RESIN BOUND SURFACE.



WE RECOMMEND A CHEAP WASHING POWDER AS AN EXCELLENT DETERGENT & TREATMENT FOR MOSS, WEEDS & GENERAL DIRT & GRIME – SCATTER LIBERALLY OVER ENTIRE SURFACE & BRUSH IN – DO NOT WATER IN OR WASH – LEAVE FOR 2 WEEKS FOR BEST RESULTS. **IMPORTANT** :- SURFACE MAY BECOME SLIPPERY SO A SALT OR SAND WILL NEED TO BE APPLIED TO AID GRIP WHILST POWDER ON SURFACE.



WASHING UP LIQUID AND WATER IS RECOMMENDED TO REMOVE OIL STAINS – REMOVE AS SOON AS POSSIBLE FOR BEST RESULTS.



SALT AND DE-ICERS CAN BE USED AND ARE RECOMMENDED IN ICY CONDITIONS – THEY HAVE NO EFFECT ON THE RESIN BOUND SURFACE.



IF YOU HAVE A RECESSED MANHOLE COVER INSTALLED, PLEASE ENSURE YOU UNDO THE SCREWS BEFORE ATTEMPTING TO REMOVE BLACK PLASTIC HANDLES



IF YOU NOTICE ANY DAMAGED AREAS TO YOUR RESIN BOUND SURFACE, CONTACT US AS SOON AS POSSIBLE ON 01202 499270 AS SMALLER AREAS CAN BE VERY EASILY REPAIRED.